

**ViewSonic**  
**Online User**  
**Guide**  
**Database**

# VP2776


---

Версия от 07:10, 1 декабря 2022; **Rob.vsi** ([обсуждение](#) | [вклад](#))  
([разн.](#)) ← [Предыдущая версия](#) | Текущая версия (разн.) | Следующая версия →  
(разн.)


## Package Contents

- Monitor
- Power cord
- Video cable
- Quick start guide

## Front View / Rear View




*Front View*



*Rear View*


Letter	Item
A	Display Screen
B	Joy Key
C	Power Button
D	Security Slot

I/O Ports



Number	Item
1	AC IN
2	HDMI
3	DisplayPort
4	USB Type-C
5	Audio Out
6	USB Type-B (Upstream)
7	USB Type-C 5V/3A
8	USB Type-A (Downstream)
9	Micro USB

Product Overview - ColorPro™ Wheel



Number	Item
1	Confirm Button
2	Dial
3	Grip
4	Back Button
5	Lens Cap
6	Lens
7	Adjustable Weight

## Stand Installation

1. Place the monitor on a flat, stable surface with the screen facing down.
2. Align and slide the upper hooks of the monitor stand into the stand mounting slots.
3. Lift the device into its upright position on a flat, stable surface.



Always place the device on a flat, stable surface.  
Failure to do so may cause the device to fall and  
damage the device and/or result in personal injury.

## Wall Mounting

Refer to the table below for the standard dimensions for wall mount kits.


For use only with a UL certified wall mount  
kit/bracket. To obtain a wall-mounting kit or height  
adjustment base, contact ViewSonic® or your local  
dealer.

Maximum Loading	Hole Pattern (W x H)	Interface Pad (W x H x D)	Pad Hole	Screw Specification & Quantity
14 kg	100 x 100 mm	115 x 115 x 2.6 mm	Ø 5 mm	M4 x 10 mm - 4 pieces

1. Turn off the device and disconnect all cables.
2. Place the device on a flat, stable surface with the screen facing down.
3. Pull down slightly to disengage the hooks and remove the stand.




4. Attach the mounting bracket to the VESA mounting holes at the rear of the monitor. Then secure it with four (4) screws (M4 x 10 mm).
5. Follow the instructions that come with the wall mounting kit to mount the monitor onto the wall.




## Installing the Shade Hood


1. Place the monitor upright on a flat, stable surface. Make sure the monitor is rotated to the landscape mode.



2. Prepare the shade hood by folding the side panels down.



3. Attach the shade hood to the top of the monitor by aligning the shape bar inside the hood with the one on top of the monitor. Repeat for the left and right sides.




4. Press down on the shade hood to fix it firmly in place.

## Using the Security Slot

To help prevent the device from being stolen, use a security slot locking device to secure the device to a fixed object.

Additionally, fastening the monitor to a wall or fixed object using a security cable can help support the weight of the monitor in order to prevent the monitor from falling over.

Below is an example of setting up a security slot locking device on a table.




## Connecting to Power


1. Connect the power cord to the AC IN jack at the rear of the device.
2. Connect the power cord plug to a power outlet.

## Connecting External Devices


**Note:** To connect the monitor to an external device (PC, laptop...etc.), please use one of the included video cables and connect it to both terminals.




Connecting to Power




HDMI Connection



DisplayPort Connection



USB Connection



Audio Connection

## HDMI

Connect one end of an HDMI cable to the HDMI port of your monitor. Then connect the other end of the cable to the HDMI port of your computer.

**NOTE:** The monitor is equipped with two HDMI 2.0 ports.

## DisplayPort

Connect one end of a DisplayPort cable to the DisplayPort port. Then connect the other end of the cable to the DisplayPort or mini DP port of your computer.

**NOTE:** To connect the monitor to the Thunderbolt port (v. 1&2) on your Mac, connect the mini DP end of the “mini DP to DisplayPort cable” to the Thunderbolt output of your Mac. Then connect the other end of the cable to the DisplayPort port of the monitor.

## USB

Connect one end of a USB cable to a USB port of the monitor. Then connect the other end of the cable to a USB port of your computer.

USB	Number	Description
Type A	Two (2)	<p>Connection for your Type A peripheral device(s). (e.g., storage device).</p> <p><b>NOTE:</b> To use some peripherals, please ensure your computer is also connected to the monitor's USB Type B port.</p>
Type B	One (1)	<p>Connect the USB Type B male cable (square with 2 cut corners) to this port, and then connect the other end of the cable to the USB downstream port of your computer.</p>
Type C	Two (2)	<p>Make sure your Type C output device and cable support video signal transmission.</p> <p><b>NOTE:</b> Only the <b>Type-C</b> port supports video transmission; the <b>Type-C 5V/3A</b> port only supports power delivery and data transmission.</p>
Micro USB	One (1)	<p>For use with the ColorPro™ Wheel.</p>



## Audio Connection

Plug the audio jack of the ear-/headphones into the Audio Out port of the monitor. Additionally, you can connect the monitor to a sound bar using an audio cable.

**NOTE:** The monitor is also equipped with dual speakers.

## Connecting the ColorPro™ Wheel

Connect the USB Type A and Micro USB cable of the ColorPro™ Wheel to the USB Type A and Micro USB port of the monitor.



*Height Adjustment*

*Swivel Adjustment*

*Tilt Angle Adjustment*

## Height Adjustment

Lower or raise the monitor to the desired height (0 to 130 mm).

**NOTE:** When adjusting, press down firmly along the adjustment track holding the monitor with both hands on the side.



## Swivel Adjustment


Swivel the monitor to the left or right for the desired viewing angle (60°).

## Tilt Angle Adjustment


Tilt the monitor forwards or backwards to the desired viewing angle (-5° to 21°).

**NOTE:** When adjusting, support the stand firmly with one hand while tilting the monitor forwards or backwards with the other hand.


## Screen Orientation Adjustment (Monitor Pivot)



*Screen Orientation Adjustment*



*Screen Orientation Adjustment*




*Screen Orientation Adjustment*

1. Adjust the monitor height to the highest position. Then tilt the monitor backwards to the full tilt position.
2. Rotate the monitor 90° clockwise or counter clockwise from landscape to portrait orientation.

### NOTE:

- When adjusting, make sure to hold both sides of your monitor firmly with both hands.
- If using the Auto Pivot function, the system can detect the screen orientation automatically.

## Turning the Device On/Off




1. Plug the power cord into a power outlet.
2. Press the Power button to turn on the monitor.
3. To turn the monitor off, press the Power button again.

**NOTE:** The monitor will still consume some power as long as the power cord is connected to the power outlet. If the monitor is not being used for a long period of time, please disconnect the power plug from the power outlet.

## Using Joy Key


Use the Joy Key to access the Startup Menu, activate Hot Keys, navigate the On-Screen Display (OSD) Menu, and change the settings.



## Startup Menu

Move the Joy Key ◀ to activate the Startup Menu.

**NOTE:** Follow the key guide that appears on the screen to select the option or make adjustments.





Main Menu



Color Mode



ViewMode



Brightness



Input














Volume

Name	Description
Main Menu	Enter the On-Screen Display (OSD) Menu.
Color Mode	Select one of the preset standard color settings.
ViewMode	Select one of the preset display settings.
Brightness	Adjust the brightness level.
Input	Select the input source.
Volume	Adjust the volume settings.

Hot Keys



When the On-Screen Display (OSD) Menu is off, you can quickly access special functions by using the Joy Key.

Key	Description
	<p>Press and hold the key for 5 seconds to activate/deactivate LED lighting.</p> 
	<p>Press and hold the key to lock/unlock the OSD Menu.</p> <p>When the menu appears on the screen, continue holding the key for 10 seconds to lock/unlock the OSD Menu.</p> 
	<p>Press and hold the key to lock/unlock the Power button.</p> <p>When the menu appears on the screen, continue holding the key for 10 seconds to lock/unlock the Power button.</p> 
	<p>Press and hold the key for 10 seconds to display/hide the boot up screen when the device is turned on.</p>

	
	<p>Press and hold the key for 10 seconds to activate/deactivate Ultra Fast.</p> 
	<p>Press and hold the key for 2 seconds to activate the KVM feature.</p>

**ColorPro™ Wheel Hot Keys**

Apart from the Joy Key, the ColorPro™ Wheel also provides a quick way to access special functions when the On-Screen Display (OSD) Menu is off.

Key	Description
	Press and hold the key for 2 seconds to activate/deactivate LED lighting.
	Press the key to activate the KVM feature when in PBP Mode.

General Operation

1. Move the joy key ◀ to display the Startup Menu. Then navigate to **Main Menu** and press the ● key to display the OSD Menu.



2. Move the joy key ▲ or ▼ to select the main menu. Then press the ● key to enter the selected menu.



3. Move the joy key ▲ or ▼ to select the desired menu option. Then press the ● key to enter the sub-menu.





4. Move the joy key ▲ or ▼ to adjust/select the setting. Then press the ● key to confirm.




5. Move the joy key ◀ to return to the previous menu.

**ColorPro™ Wheel for OSD Control**




Apart from the Joy Key, the ColorPro™ Wheel also provides a quick way to control and access the OSD menus.

**Using the ColorPro™ Wheel**

Enter the On-Screen Display (OSD) Menu  
Enter the OSD Menu by pressing the *Confirm Button*.





Select an Option and Confirm  
Rotate the *Dial* to select an option, and press the *Confirm Button* to confirm.




### Adjust the Value

Rotate the *Dial* left or right to adjust the value of the selected option.



### Back

Press *Back Button* the at any time to return to the previous option.



OSD Tree

Input Select

Sub-menu	Menu Option	
DisplayPort	Color Format	Auto
		RGB (Full Range)
		RGB (Limited Range)
		YUV (Full Range)
		YUV (Limited Range)
	DisplayPort 1.4	On
		Off
HDMI 1	Color Format	Auto
		RGB (Full Range)
		RGB (Limited Range)
		YUV (Full Range)
		YUV (Limited Range)
	HDMI 2.0	On
		Off
HDMI 2	Color Format	Auto
		RGB (Full Range)
		RGB (Limited Range)
		YUV (Full Range)
		YUV (Limited Range)

Type C	HDMI 2.0	On
		Off
	Color Format	Auto
		RGB (Full Range)
		RGB (Limited Range)
		YUV (Full Range)
		YUV (Limited Range)
	USB 3.2	On
		Off
	DisplayPort 1.4	On
		Off
	Auto Detect	On
		Off

Color Mode

Sub-menu	Menu Option		
DCI-P3	Brightness	(-/+, 0~100)	
	Color Temperature	9300K	
		7500K	
		6500K	
		6300K	
		5000K	
	Gamma	1	
		1.4	
		1.8	
		2.2	
		2.4	
		2.6	
	Sharpness	(-/+, 0~100)	
	Aspect Ratio	1:1	
		4:3	
		Full Screen	
	Uniformity	On	

		Off	
	Recall		
<b>sRGB</b>	Brightness	(-/+, 0~100)	
	Color Temperature	9300K	
		7500K	
		6500K	
		6300K	
		5000K	
	Gamma	1	
		1.4	
		1.8	
		2.2	
		2.4	
		2.6	
	Sharpness	(-/+, 0~100)	
	Aspect Ratio	1:1	
		4:3	
		Full Screen	
	Uniformity	On	
		Off	
	Recall		
<b>REC709</b>	Brightness	(-/+, 0~100)	
	Color Temperature	9300K	
		7500K	
		6500K	
		6300K	
		5000K	
	Gamma	1	
		1.4	
		1.8	
		2.2	
		2.4	
		2.6	
	Sharpness	(-/+, 0~100)	
	Aspect Ratio	1:1	
		4:3	

		Full Screen	
	Uniformity	On	
		Off	
	Recall		
<b>DICOM-SIM</b>	Sharpness	(-/+, 0~100)	
	Aspect Ratio	1:1	
		4:3	
		Full Screen	
<b>User</b>	Contrast	(-/+, 0~100)	
	Brightness	(-/+, 0~100)	
	Color Temperature	9300K	
		7500K	
		6500K	
		6300K	
		5000K	
	Gamma	1	
		1.4	
		1.8	
		2.2	
		2.4	
		2.6	
	Advanced DCR	(-/+, 0/25/50/75/100)	
	Gain	Red	(-/+, 0~100)
		Green	(-/+, 0~100)
		Blue	(-/+, 0~100)
	Offset	Red	(-/+, 0~100)
		Green	(-/+, 0~100)
		Blue	(-/+, 0~100)
	Hue	Red	(-/+, 0~100)
		Green	(-/+, 0~100)

		Blue	(-/+, 0~100)
		Cyan	(-/+, 0~100)
		Magenta	(-/+, 0~100)
		Yellow	(-/+, 0~100)
	Sharpness	(-/+, 0~100)	
	Aspect Ratio	1:1	
		4:3	
		Full Screen	
	Blue Light Filter	(-/+, 0~5)	
	Uniformity	On	
		Off	
	Recall		

## ViewMode

Sub-menu	Menu Option	
<b>CAD/CAM</b>	Ultra Clear	(-/+, 0~4)
	Advanced-Sharpness	(-/+, 0~100)
	Advanced-Gamma	(-/+, 1.8~2.6)
<b>Video Edit</b>	Ultra Clear	(-/+, 0~4)
	Advanced-Sharpness	(-/+, 0~100)
	Advanced-Gamma	(-/+, 1.8~2.6)
<b>Animation</b>	Ultra Clear	(-/+, 0~4)
	Advanced-Sharpness	(-/+, 0~100)
	Black Stabilization	(-/+, 0~10)
<b>Photographer</b>	Ultra Clear	(-/+, 0~4)
	Advanced-Sharpness	(-/+, 0~100)
	Advanced-Gamma	(-/+, 1.8~2.6)
<b>FPS 1</b>		
<b>FPS 2</b>		

RTS	
MOBA	

Audio Adjust

Sub-menu	Menu Option
Volume	(-/+, 0~100)
Mute	On
	Off
Audio Input	DisplayPort
	HDMI 1
	HDMI 2
	Type C

Setup Menu

Sub-menu	Menu Option	
Language Select	English	
	Français	
	Deutsch	
	Español	
	Italiano	
	Suomi	
	Русский	
	Türkçe	
	日本語	
	한국어	
	繁體中文	
	简体中文	
Adaptive Sync	On	
	Off	
Resolution Notice	On	
	Off	
PureXP™	On	
	Off	
Information		
OSD Timeout	(-/+, 5/15/30/60)	



<b>OSD Background</b>	On		
	Off		
<b>OSD Pivot</b>	Auto		
	0°		
	+90°		
	-90°		
	180°		
<b>Power Indicator</b>	On		
	Off		
<b>Auto Power Off</b>	On		
	Off		
<b>Sleep</b>	30 minutes		
	45 minutes		
	60 minutes		
	120 minutes		
	Off		
<b>Multi-Picture</b>	Off		
	PBP Left-Right	Left Source Select	DisplayPort
			HDMI 1
			HDMI 2
			Type C
		Right Source Select	DisplayPort
			HDMI 1
			HDMI 2
			Type C
		Swap	
	PIP	PIP Source Select	DisplayPort
			HDMI 1
			HDMI 2
			Type C
		PIP Position	PIP H. Position
			PIP V. Position
		PIP Size	(-/+, 0~100)

		Swap		
	Dual Color	DCI-P3		
		sRGB		
		REC709		
		DICOM-SIM		
		User		
		CAL 1		
		CAL 2		
		CAL 3		
		CAD/CAM		
		Video Edit		
		Animation		
		Photographer		
		FPS 1		
		FPS 2		
		RTS		
		MOBA		
ECO Mode	Standard			
	Optimize			
	Conserve			
	Energy Saving	On		
		Off		
Overscan	On			
	Off			
Response Time	Standard			
	Advanced			
	Ultra Fast			
USB Charging	On			
	Off			
Backstage Lighting	Level 1			
	Level 2			
	Level 3			
	Off			
Burn-in Eraser	On			
	Off			
DDC/CI	On			

	Off	
Rename		
All Recall		

Input



- 1. Move the joy key ◀ to display the Startup Menu. Then navigate to **Main Menu** and press the ● key to display the OSD Menu.
- 2. Move the joy key ▲ or ▼ to select **Input**. Then press the ● key to enter the **Input** menu.
- 3. Move the joy key ▲ or ▼ to select the desired input source. Then press the ● key to confirm the selection.

Color Mode

Menu Option	Description
DCI-P3	Precise color gamut and gamma of DCI-P3 standard.
sRGB	Precise color gamut and gamma of sRGB standard.
REC709	Precise color gamut and gamma of ITU-R Rec. 709 standard.
DICOM-SIM	Gamma curves are set to a DICOM simulation.
User	Custom, user-defined settings.
CAL1/CAL2/CAL3	Display with the 1st/2nd/3rd user calibration mode.
HDR	Reduce the overall contrast of a given scene so that detail in the highlights and shadows can be seen.

- 1. Move the joy key ◀ to display the Startup Menu. Then navigate to **Main Menu** and press the ● key to display the OSD Menu.
- 2. Move the joy key ▲ or ▼ to select **Color Mode**. Then press the ● key to enter the **Color Mode** menu.
- 3. Move the joy key ▲ or ▼ to select the desired option. Then press the ● key to enter its sub-menu.
- 4. Move the joy key ▲ or ▼ to adjust/select the setting, and press the ● key to confirm the selection (if applicable).

## ViewMode

Menu Option	Description
<b>CAD/CAM</b>	Select this option for viewing graphic design files.
<b>Video Edit</b>	Select this option for video editing.
<b>Animation</b>	Select this option for animation.
<b>Photographer</b>	Select this option for viewing photo files.
<b>FPS 1</b>	Ideal for First-Person Shooter games.
<b>FPS 2</b>	Ideal for First-Person Shooter games.
<b>RTS</b>	Ideal for Real-Time Strategy games.
<b>MOBA</b>	Select this option for Multiplayer Online Battle Arena games.

1. Move the joy key ◀ to display the Startup Menu. Then navigate to **Main Menu** and press the ● key to display the OSD Menu.
2. Move the joy key ▲ or ▼ to select **ViewMode**. Then press the ● key to enter the **ViewMode** menu.
3. Move the joy key ▲ or ▼ to select the desired option. Then press the ● key to enter its sub-menu.

## Audio Adjust

Menu Option	Description
<b>Volume</b>	Adjust the volume level.
<b>Mute</b>	Enable this option to temporarily turn off the sound.
<b>Audio Input</b>	Select the audio input source.

1. Move the joy key ◀ to display the Startup Menu. Then navigate to **Main Menu** and press the ● key to display the OSD Menu.
2. Move the joy key ▲ or ▼ to select **Audio Adjust**. Then press the ● key to enter the **Audio Adjust** menu.
3. Move the joy key ▲ or ▼ to select the desired option. Then press the ● key to enter its sub-menu.
4. Move the joy key ▲ or ▼ to adjust/select the setting, and press the ● key to confirm the selection (if applicable).

## Setup Menu

Menu Option	Description
<b>Language Select</b>	Select an available language for the OSD Menu.
<b>Adaptive Sync</b>	Eliminates stuttering and tearing during gameplay.

<b>Resolution Notice</b>	Enable this option to allow the system to inform users that the current viewing resolution is not the correct native resolution.
<b>PureXP™</b>	Short for “Pure Experience”, this feature can enhance the visual quality of moving objects, making them less vague with a clearer view.
<b>Information</b>	Display the monitor information.
<b>OSD Timeout</b>	Set the length of time the OSD Menu remains on screen.
<b>OSD Background</b>	Show/Hide the OSD background when the OSD Menu appears on the screen.
<b>OSD Pivot</b>	<p>Set the OSD Menu orientation.</p> <ul style="list-style-type: none"> <li>▪ Auto: With the built-in G sensor, the OSD Menu can automatically pivot when the monitor is positioned vertically.</li> <li>▪ 0°: Sets the OSD Menu without a pivot.</li> <li>▪ +90°: Sets the OSD Menu with a +90° pivot.</li> <li>▪ 90°: Sets the OSD Menu with a -90° pivot.</li> <li>▪ 180°: Sets the OSD Menu with a 180° pivot.</li> </ul>
<b>Power Indicator</b>	Set the Power Indicator On or Off. If the setting is set to On, the power indicator lights blue when the device is turned on.
<b>Auto Power Off</b>	Enable this option to allow the monitor to automatically turn off after a certain amount of time.
<b>Sleep</b>	Set the amount of idle time before the monitor enters Sleep mode.
<b>Multi-Picture</b>	<p><u>Off</u></p> <p>Disable this function.</p> <p><u>PBP Left-Right</u> Display two windows, a 1x1 split screen, side-by-side on the left and right of the screen. User can specify the input source for each screen.</p> <p><u>PIP</u> Split the screen into two parts, a main window and an inset window. User can specify the input source for each screen.</p>

	<b>Dual Color</b> Display two different color settings in PIP or PBP mode.
<b>ECO Mode</b>	Choose between various modes, based on power consumption.
<b>Overscan</b>	Enable this option to automatically enlarge the original picture horizontally and vertically to an equal aspect ratio that fills the screen.
<b>Response Time</b>	Adjust the response time, creating smooth images without streaking, blurring or ghosting. A low response time is perfect for the most graphic-intense gaming, and provides amazing visual quality while watching sports or action movies.
<b>USB Charging</b>	Enable/disable usb charging.
<b>Backstage Lighting</b>	Adjust the LED lighting.
<b>Burn-in Eraser</b>	Reduce image burn-in.
<b>DDC/CI</b>	Enable this option to allow the monitor control via the graphics card.
<b>Rename</b>	Rename the personalized custom profile.
<b>All Recall</b>	Resets all settings to their default values.

1. Move the joy key ◀ to display the Startup Menu. Then navigate to **Main Menu** and press the ● key to display the OSD Menu.
2. Move the joy key ▲ or ▼ to select **Setup Menu**. Then press the ● key to enter the **Setup Menu** menu.
3. Move the joy key ▲ or ▼ to select the desired option. Then press the ● key to enter its sub-menu.
4. Move the joy key ▲ or ▼ to adjust/select the setting, and press the ● key to confirm the selection (if applicable).

## HDR (High-Dynamic-Range)

Reduces the overall contrast of a given scene so that detail in the highlights and shadows can be seen.

Ensure the HDR setting is turned on on your device first before enabling the HDR10 on the monitor. For example, the HDR setting on Xbox One S or PS4 Pro needs to be turned on first before enjoying your HDR10 video content.




To enable the HDR function:

1. Move the joy key ◀ to display the Startup Menu. Then navigate to **Main Menu** and press the ● key to display the OSD Menu.
2. Move the joy key ▲ or ▼ to select **Color Mode**. Then press the ● key to enter the **Color Mode** menu.
3. Move the joy key ▲ or ▼ to select **HDR**. Then press the ● key to enter its sub-menu.
4. Move the joy key ▲ or ▼ to select one of the options . Then press the ● key to confirm.

## KVM

The KVM function allows the user to control two computers connected to the same monitor from a single keyboard and mouse.

Only applicable in PBP (Picture-by-Picture) mode.



To connect the two computers to the monitor:


1. Connect one end of the USB Type C cable to the USB Type C port of the monitor. Then connect the other end of the cable to the USB Type C port of the notebook.
2. Connect one end of a DisplayPort cable to the DisplayPort of the monitor. Then connect the other end of the cable to the DisplayPort or mini DP of the computer.
3. Connect the USB Type B male cable (square with 2 cut corners) to the USB Type B port of the monitor. Then connect the other end of the cable to the USB port of the computer.

To enable PBP mode:

1. Move the joy key ◀ to display the Startup Menu. Then navigate to **Main Menu** and press the ● key to display the OSD Menu.
2. Move the joy key ▲ or ▼ to select the **Setup Menu** menu. Then press the ● key to enter the menu.
3. Move the joy key ▲ or ▼ to select **Multi-Picture**. Then press the ● key to enter its sub-menu.
4. Move the joy key ▲ or ▼ to select **PBP Left-Right**. Then press the ● key to enable PBP mode.

To activate the KVM function:


1. Press and hold the ▶ key for two (2) seconds to activate the KVM function.
2. Then you will be able to switch the cursor between the two screens (left/right window).



## Auto Pivot

With the Auto Pivot function, the monitor can detect the image display and adjust the image's orientation on the screen automatically when pivoting the screen vertically or horizontally.

**NOTE:** The Auto Pivot function uses DDC/CI to communicate with the monitor. Before applying the Auto Pivot function, please make sure the DDC/CI setting is set to **On**.



To enable the DDC/CI setting:

1. Open the OSD Menu and select the **Setup Menu** menu. Then press the ● key to enter the menu.
2. Move the joy key ▲ or ▼ to select **DDC/CI**. Then press the ● key to enter its sub-menu.
3. Move the joy key ▲ or ▼ to select **On**. Then press the ● key to confirm.



After ensuring **DDC/CI** is **On**, proceed to set **OSD Pivot** to **Auto**:

1. Open the OSD Menu and select the **Setup Menu** menu. Then press the **•** key to enter the menu.
2. Move the joy key **▲** or **▼** to select **OSD Pivot**. Then press the **•** key to enter its sub-menu.
3. Move the joy key **▲** or **▼** to select **Auto**. Then press the **•** key to confirm.

## Colorbration+

To ensure long-term color accuracy, some specific models support the hardware color calibration function. The Colorbration+ application installation file can be found at: <http://color.viewsonic.com/support/software/> <  
<http://color.viewsonic.com/support/software/>> .

Standard monitor packing does not include the color sensor, which the Colorbration+ application needs for the calibration process.


Compatible color sensors include:

- X-Rite i1 Display Pro
- X-Rite i1 Pro 2
- X-Rite i1 Studio
- Xrite Colormunki Photo
- Xrite Colormunki Design
- Datacolor Spyder 5
- Datacolor SpyderX series

## Dual Color

The monitor comes with a dual color engine to display two different color settings in PIP (Picture-in-Picture) or PBP mode. You can set different color presets in both windows (Main Window and Secondary Window).

**NOTE:** To enable PIP or PBP mode, refer to the **Multi-Picture** section.



To configure Dual Color:

1. Move the joy key ◀ to display the **Startup Menu**. Then navigate to **Main Menu** and press the ● key to display the OSD Menu.
2. Move the joy key ▲ or ▼ to select the **Setup Menu** menu. Then press the ● key to enter the menu.
3. Move the joy key ▲ or ▼ to select **Multi-Picture**. Then press the ● key to enter its sub-menu.
4. Move the joy key ▲ or ▼ to select **Dual Color**. Then press the ● key to enter its sub-menu.
5. Move the joy key ▲ or ▼ to select the desired color setting. Then press the ● key to confirm.

## Multi-Picture


Multi-Picture allows users to further customize their work space by allowing up to four split windows from different inputs, displaying high resolution content with different aspect ratios, without distortion from the original input sources.

To enable Multi-Picture mode:

1. Move the joy key ◀ to display the **Startup Menu**. Then navigate to **Main Menu** and press the ● key to display the OSD Menu.
2. Move the joy key ▲ or ▼ to select **Color Mode**. Then press the ● key to enter the Color Mode menu.
3. Move the joy key ▲ or ▼ to select **Multi-Picture**. Then press the ● key to enter its sub-menu.
4. Move the joy key ▲ or ▼ to select **PBP Left-Right** or **PIP**. Then press the ● key to enter the selected mode.

## PBP (Picture-by-Picture)

---




To configure PBP:

1. Move the joy key ◀ to display the **Startup Menu**. Then navigate to **Main Menu** and press the ● key to display the OSD Menu.
2. Move the joy key ▲ or ▼ to select **Setup Menu**. Then press the ● key to enter the **Setup Menu** menu.
3. Move the joy key ▲ or ▼ to select **Multi-Picture**. Then press the ● key to enter its sub-menu.
4. Move the joy key ▲ or ▼ to select **PBP Left-Right**. Then press the ● key to enter its sub-menu.
5. To change the input source, select the source location (**Left Source Select/Right Source Select**) and press the ● key.
6. Move the joy key ▲ or ▼ to select the desired input source and press the ● key to confirm.
7. To swap the two windows, select **Swap** and press the ● key to confirm.

## PIP (Picture-in-Picture)

---



To configure PIP:

1. Move the joy key ◀ to display the **Startup Menu**. Then navigate to **Main Menu** and press the ● key to display the OSD Menu.
2. Move the joy key ▲ or ▼ to select **Setup Menu**. Then press the ● key to enter the **Setup Menu** menu.
3. Move the joy key ▲ or ▼ to select **Multi-Picture**. Then press the ● key to enter its sub-menu.
4. Move the joy key ▲ or ▼ to select **PIP**. Then press the ● key to enter its sub-menu.
5. To change the input source for the Inset Window, select **PIP Source Select** and press the ● key. Then move the joy key ▲ or ▼ to select the desired input source and press the ● key to confirm.
6. To adjust the Inset Window position, select **PIP Position** and press the ● key.
  - Press the ● key to select **PIP H.Position** or **PIP V.Position**.
  - Move the joy key ▲ or ▼ to adjust the setting and press the ● key to confirm.
7. To adjust the Inset Window size, select **PIP Size** and press the ● key. Then move the joy key ▲ or ▼ to adjust the setting.
8. To swap the two windows, select **Swap** and press the ● key to confirm.

## Backstage Lighting

With the Backstage Lighting function, the monitor can adjust the LED brightness to the optimal settings.


To configure the Backstage Lighting settings:

1. Open the OSD Menu and select the **Setup Menu** menu. Then touch the **•** key to enter the menu.
2. Move the joy key **▲** or **▼** to select **Backstage Lighting**. Then touch the **•** key to enter its sub-menu.
3. Move the joy key **▲** or **▼** to select **Level 1**, **Level 2**, or **Level 3** to enable the function. Then touch the **•** key to confirm.

## Firmware Update

For the best display performance and to resolve any known issues, it is best to keep your monitor updated with the latest firmware version. With the supplied USB cable and the vDisplayManager application, you can easily update your monitor's firmware.

To update the firmware:



1. Download and install the vDisplayManager application:  
<https://color.viewsonic.com/support/software/<https://color.viewsonic.com/support/software/>> .
2. Connect the USB Type B male cable (square with 2 cut corners) to the USB Type B port of your monitor. Then connect the other end of the cable to the USB port of the computer.
3. Launch vDisplayManager. Select the **Advanced** tab in the side menu.
4. Click **Update** to check for any updates to your monitor's firmware.
5. Wait until the update process is complete (if applicable).

**NOTE:** Any interruptions during the firmware update process may permanently damage your monitor. Do not disconnect the USB cable or turn off your PC and monitor.

## What is Colorbration+?

Color accuracy is one of the most important aspects of the creative workflow and ensuring that your monitor's color accurately represents the color of your original image or digital file is essential. The software allows you to:

- Calibrate and profile your monitor quickly and easily.
- Control white point, luminance, contrast ratio, gamma, and more.
- Save time, money, guesswork, and frustration that generally comes with monitor calibration.
- Focus on your work with complete confidence.

## Where to Get Colorbration+?

The Colorbration<sup>+</sup> software can be downloaded at:  
<https://color.viewsonic.com/support/software>

<https://color.viewsonic.com/support/software>


After the download completes, launch the Setup file and follow the on-screen directions to install the software.

## Connection Methods

In addition to downloading the software, ensure that your monitor, computer and ColorPro<sup>™</sup> Wheel are properly connected. There are two methods of connection for your monitor and computer:


### HDMI or DisplayPort

Users with an HDMI or DisplayPort connection should also connect their monitor and computer via a USB Type B to USB Type A cable.




### USB Type C

Users with a USB Type C connection can connect their monitor and computer directly.




## Connecting the ColorPro<sup>™</sup> Wheel

Connect the USB Type A and Micro USB cable of the ColorPro<sup>™</sup> Wheel to the USB Type A and Micro USB port of the monitor.




## Preparing for Color Calibration

1. Ensure all connections have been made and are correct.
2. Tilt your monitor slightly upwards.




3. Remove the *Lens Cap* and carefully place the measurement device in contact with the monitor's screen.



## Using Colorbration+

Upon initially launching Colorbration+ the user will have two modes to choose from:

- Basic Mode
- Advanced Mode



**NOTE:** For more detailed information, please see the [Colorbration+ user guide](#).

## General Operation

---

To begin the Advanced Mode calibration process:

- 1. Select Device Selection, then the monitor you wish to calibrate from the available options.
- 2. Connect and select the measurement device you wish to use from the available options.
- 3. Select Calibration on the Sidebar Menu.
- 4. Choose your desired calibration settings from the drop-down menu, or create a custom profile
- 5. Once the calibration settings have been chosen, select to begin the calibrating process.
- 6. Wait until the color calibration process is complete.

**NOTE:** Any interruptions during the color calibration process may permanently damage your monitor color. Do not disconnect the USB cable or turn off your PC or monitor.

Technical Specifications

---



Model No.	P/N
VS18610	VP2776



Item	Category	Specifications
<b>LCD</b>	Type	IPS type, TFT  Active Matrix 2560 x 1440 LCD, 0.2331 mm x 0.2331 mm pixel pitch
	Display Size	68.47 cm, 27"
	Color Filter	RGB vertical stripe
	Glass Surface	Anti-Glare type, Hard Coating (3H)
<b>Input Signal</b>	Video Sync	<u>TMDS digital (100 Ω)</u>  HDMI: fh:15-204 kHz, fv:24-120 Hz  DisplayPort: fh:15-204 kHz, fv:24-120 Hz
<b>Compatibility</b>	PC	up to 2560 x 1440
	Macintosh	up to 2560 x 1440

	Recommended	2560 x 1440 @ 165Hz
<b>Resolution<sup>[1]</sup></b>	Supported	<ul style="list-style-type: none"> <li>▪ 2560 x 1440 @ 60, 165Hz</li> <li>▪ 2048 x 1152 @ 60Hz</li> <li>▪ 1920 x 1440 @ 60Hz</li> <li>▪ 1920 x 1200 @ 60Hz</li> <li>▪ 1920 x 1080 @ 50, 60Hz</li> <li>▪ 1680 x 1050 @ 60Hz</li> <li>▪ 1600 x 1200 @ 60Hz</li> <li>▪ 1600 x 900 @ 60Hz</li> <li>▪ 1440 x 900 @ 60, 75Hz</li> <li>▪ 1400 x 1050 @ 60, 75Hz</li> <li>▪ 1366 x 768 @ 60Hz</li> <li>▪ 1360 x 768 @ 60Hz</li> <li>▪ 1280 x 1024 @ 50, 60, 75Hz</li> <li>▪ 1280 x 960 @ 50, 60, 75Hz</li> <li>▪ 1280 x 800 @ 60Hz</li> <li>▪ 1280 x 768 @ 50, 60Hz</li> <li>▪ 1280 x 720 @ 50, 60Hz</li> <li>▪ 1152 x 900 @ 67Hz</li> <li>▪ 1152 x 864 @ 75Hz</li> <li>▪ 1024 x 768 @ 50, 60, 70, 72, 75Hz</li> <li>▪ 848 x 480 @ 60Hz</li> <li>▪ 800 x 600 @ 56, 60, 72Hz</li> <li>▪ 720 x 576 @ 50Hz</li> <li>▪ 720 x 480 @ 60Hz</li> <li>▪ 720 x 400 @ 70Hz</li> <li>▪ 640 x 480 @ 50, 60, 67, 72Hz</li> <li>▪ 640 x 400 @ 60, 70Hz</li> <li>▪ 640 x 350 @ 70Hz</li> </ul>
<b>Power Adapter<sup>[2]</sup></b>	Input Voltage	AC 100-240V, 50/60Hz (auto switch)
<b>Display Area</b>	Full Scan (H x V)	596.74 x 335.66 mm (23.49" x 13.21")
<b>Operating Conditons</b>	Temperature	0° C to 40° C (32° F to 104° F)

	Humidity	20% to 90% (non-condensing)
	Altitude	16,404 feet (4.9 km)
<b>Storage Conditions</b>	Temperature	-20° C to 60° C (-4° F to 140° F)
	Humidity	5% to 90% (non-condensing)
	Altitude	40, 000 feet (12.1 km)
<b>Dimensions</b>	Physical (W x H x D)	613.70 x 569.36~449.36 x 234 mm  (24.16" x 22.42~17.69" x 9.21")
<b>Wall Mount</b>	Dimensions	100 x 100 mm
<b>Weight</b>	Physical	9.55 kg (21.05 lbs)
<b>Power Saving Modes</b>	On <sup>[3]</sup>	32W (Typical)
	Off	< 0.3W (Max)

1. Do not set the graphics card in your computer to exceed these timing modes; doing so may result in permanent damage to the display.
2. Please use the power adapter from ViewSonic® or an authorized source only.
3. The test condition follows EEL standards.

## Compliance Information

---

This section addresses all connected requirements and statements regarding regulations. Confirmed corresponding applications shall refer to nameplate labels and relevant markings on the unit.

### FCC Compliance Statement

This device complies with part 15 of FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a

particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**Warning:** You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

### Industry Canada Statement

CAN ICES-003(B) / NMB-003(B)

### CE Conformity for European Countries



The device complies with the EMC Directive 2014/30/EU and Low Voltage Directive 2014/35/EU.

### The following information is only for EU-member states:

The mark shown to the right is in compliance with the Waste Electrical and Electronic Equipment Directive 2012/19/EU (WEEE). The mark indicates the requirement NOT to dispose of the equipment as unsorted municipal waste, but use the return and collection systems according to local law.



### Declaration of RoHS2 Compliance

---

This product has been designed and manufactured in compliance with Directive 2011/65/EU of the European Parliament and the Council on restriction of the use of certain hazardous substances in electrical and electronic equipment (RoHS2 Directive) and is deemed to comply with the maximum concentration values issued by the European Technical Adaptation Committee (TAC) as shown below:

Substance	Proposed Maximum Concentration	Actual Concentration
Lead (Pb)	0.1%	< 0.1%
Mercury (Hg)	0.1%	< 0.1%
Cadmium (Cd)	0.01%	< 0.01%
Hexavalent Chromium (Cr6 <sup>+</sup> )	0.1%	< 0.1%
Polybrominated biphenyls (PBB)	0.1%	< 0.1%
Polybrominated diphenyl ethers (PBDE)	0.1%	< 0.1%
Bis (2-ethylhexyl) phthalate (DEHP)	0.1%	< 0.1%
Butyl benzyl phthalate (BBP)	0.1%	< 0.1%
Dibutyl phthalate (DBP)	0.1%	< 0.1%
Diisobutyl phthalate (DIBP)	0.1%	< 0.1%

**Certain components of products as stated above are exempted under the Annex III of the RoHS2 Directives as noted below. Examples of exempted components are:**

- Lead as an alloying element in aluminum containing up to 0.4% lead by weight.
- Copper alloy containing up to 4% lead by weight.
- Lead in high melting temperature type solders (i.e. lead-based alloys containing 85% by weight or more lead).
- Electrical and electronic components containing lead in a glass or ceramic other than dielectric ceramic in capacitors, e.g. piezoelectronic devices, or in a glass or ceramic matrix compound.

### Indian Restriction of Hazardous Substances

---

Restriction on Hazardous Substances statement (India). This product complies with the “India E-waste Rule 2011” and prohibits use of lead, mercury, hexavalent chromium, polybrominated biphenyls or polybrominated diphenyl ethers in concentrations exceeding 0.1 weight % and 0.01 weight % for cadmium, except for the exemptions set in Schedule 2 of the Rule.

### Product Disposal at End of Product Life

---

ViewSonic® respects the environment and is committed to working and living green. Thank you for being part of Smarter, Greener Computing. Please visit the ViewSonic® website to learn more.

### USA & Canada

<https://www.viewsonic.com/us/company/green/go-green-with-viewsonic/#recycle-program> < <https://www.viewsonic.com/us/company/green/go-green-with->

[viewsonic/#recycle-program>](#)

## Europe

[<](http://www.viewsoniceurope.com/eu/support/call-desk/)

[>](http://www.viewsoniceurope.com/eu/support/call-desk/)

## Taiwan

[<](https://recycle.epa.gov.tw/) [https://recycle.epa.gov.tw/>](https://recycle.epa.gov.tw/)

## Copyright Information

---

Copyright© ViewSonic® Corporation, 2021. All rights reserved.

Macintosh and Power Macintosh are registered trademarks of Apple Inc.

Microsoft, Windows, and the Windows logo are registered trademarks of Microsoft Corporation in the United States and other countries.

ViewSonic®, the three birds logo, OnView, ViewMatch, and ViewMeter are registered trademarks of ViewSonic® Corporation.

VESA is a registered trademark of the Video Electronics Standards Association. DPMS, DisplayPort, and DDC are trademarks of VESA.

ENERGY STAR® is a registered trademark of the U.S. Environmental Protection Agency (EPA).

As an ENERGY STAR® partner, ViewSonic® Corporation has determined that this product meets the ENERGY STAR® guidelines for energy efficiency.

**Disclaimer:** ViewSonic® Corporation shall not be liable for technical or editorial errors or omissions contained herein; nor for incidental or consequential damages resulting from furnishing this material, or the performance or use of this product.

In the interest of continuing product improvement, ViewSonic® Corporation reserves the right to change product specifications without notice. Information in this document may change without notice.

No part of this document may be copied, reproduced, or transmitted by any means, for any purpose without prior written permission from ViewSonic® Corporation.

VP2776\_UG\_ENG\_1c\_20221128

## Customer Service Contact Information

For technical support or product service, see the table below or contact your reseller.

You will need the product's serial number

## Asia Pacific & Africa

Country / Region	Website
Australia	<a href="https://viewsonic.com/au/">https://viewsonic.com/au/</a> < <a href="https://viewsonic.com/au/">https://viewsonic.com/au/</a> >
Bangladesh	<a href="https://www.viewsonic.com/bd/">https://www.viewsonic.com/bd/</a> < <a href="https://www.viewsonic.com/bd/">https://www.viewsonic.com/bd/</a> >
中国(China)	<a href="https://www.viewsonic.com.cn">https://www.viewsonic.com.cn</a> < <a href="https://www.viewsonic.com.cn">https://www.viewsonic.com.cn</a> >
香港 (繁體中文)	<a href="https://www.viewsonic.com/hk/">https://www.viewsonic.com/hk/</a> < <a href="https://www.viewsonic.com/hk/">https://www.viewsonic.com/hk/</a> >
Hong Kong (English)	<a href="https://www.viewsonic.com/hk-en/">https://www.viewsonic.com/hk-en/</a> < <a href="https://www.viewsonic.com/hk-en/">https://www.viewsonic.com/hk-en/</a> >
India	<a href="https://www.viewsonic.com/in/">https://www.viewsonic.com/in/</a> < <a href="https://www.viewsonic.com/in/">https://www.viewsonic.com/in/</a> >
Indonesia	<a href="https://www.viewsonic.com/id/">https://www.viewsonic.com/id/</a> < <a href="https://www.viewsonic.com/id/">https://www.viewsonic.com/id/</a> >
Israel	<a href="https://www.viewsonic.com/il/">https://www.viewsonic.com/il/</a> < <a href="https://www.viewsonic.com/il/">https://www.viewsonic.com/il/</a> >
日本 (Japan)	<a href="https://www.viewsonic.com/jp/">https://www.viewsonic.com/jp/</a> < <a href="https://www.viewsonic.com/jp/">https://www.viewsonic.com/jp/</a> >
Korea	<a href="https://www.viewsonic.com/kr/">https://www.viewsonic.com/kr/</a> < <a href="https://www.viewsonic.com/kr/">https://www.viewsonic.com/kr/</a> >
Malaysia	<a href="https://www.viewsonic.com/my/">https://www.viewsonic.com/my/</a> < <a href="https://www.viewsonic.com/my/">https://www.viewsonic.com/my/</a> >
Middle East	<a href="https://www.viewsonic.com/me/">https://www.viewsonic.com/me/</a> < <a href="https://www.viewsonic.com/me/">https://www.viewsonic.com/me/</a> >
Myanmar	<a href="https://www.viewsonic.com/mm/">https://www.viewsonic.com/mm/</a> < <a href="https://www.viewsonic.com/mm/">https://www.viewsonic.com/mm/</a> >
Nepal	<a href="https://www.viewsonic.com/np/">https://www.viewsonic.com/np/</a> < <a href="https://www.viewsonic.com/np/">https://www.viewsonic.com/np/</a> >
New Zealand	<a href="https://www.viewsonic.com/nz/">https://www.viewsonic.com/nz/</a> < <a href="https://www.viewsonic.com/nz/">https://www.viewsonic.com/nz/</a> >
Pakistan	<a href="https://www.viewsonic.com/pk/">https://www.viewsonic.com/pk/</a> < <a href="https://www.viewsonic.com/pk/">https://www.viewsonic.com/pk/</a> >
Philippines	<a href="https://www.viewsonic.com/ph/">https://www.viewsonic.com/ph/</a> < <a href="https://www.viewsonic.com/ph/">https://www.viewsonic.com/ph/</a> >
Singapore	<a href="https://www.viewsonic.com/sg/">https://www.viewsonic.com/sg/</a> < <a href="https://www.viewsonic.com/sg/">https://www.viewsonic.com/sg/</a> >
臺灣 (Taiwan)	<a href="https://www.viewsonic.com/tw/">https://www.viewsonic.com/tw/</a> < <a href="https://www.viewsonic.com/tw/">https://www.viewsonic.com/tw/</a> >
ประเทศไทย (Thailand)	<a href="https://www.viewsonic.com/th/">https://www.viewsonic.com/th/</a> < <a href="https://www.viewsonic.com/th/">https://www.viewsonic.com/th/</a> >

<b>Việt Nam</b>	<a href="https://www.viewsonic.com/vn/">https://www.viewsonic.com/vn/</a> < <a href="https://www.viewsonic.com/vn/">https://www.viewsonic.com/vn/</a> >
<b>South Africa &amp; Mauritius</b>	<a href="https://www.viewsonic.com/za/">https://www.viewsonic.com/za/</a> < <a href="https://www.viewsonic.com/za/">https://www.viewsonic.com/za/</a> >

## Americas

---

Country / Region	Website
<b>United States</b>	<a href="https://www.viewsonic.com/us/">https://www.viewsonic.com/us/</a> < <a href="https://www.viewsonic.com/us/">https://www.viewsonic.com/us/</a> >
<b>Canada</b>	<a href="https://www.viewsonic.com/us/">https://www.viewsonic.com/us/</a> < <a href="https://www.viewsonic.com/us/">https://www.viewsonic.com/us/</a> >
<b>Latin America</b>	<a href="https://www.viewsonic.com/la/">https://www.viewsonic.com/la/</a> < <a href="https://www.viewsonic.com/la/">https://www.viewsonic.com/la/</a> >

## Europe

---

Country / Region	Website
<b>Europe</b>	<a href="https://www.viewsonic.com/eu/">https://www.viewsonic.com/eu/</a> < <a href="https://www.viewsonic.com/eu/">https://www.viewsonic.com/eu/</a> >
<b>France</b>	<a href="https://www.viewsonic.com/fr/">https://www.viewsonic.com/fr/</a> < <a href="https://www.viewsonic.com/fr/">https://www.viewsonic.com/fr/</a> >
<b>Deutschland</b>	<a href="https://www.viewsonic.com/de/">https://www.viewsonic.com/de/</a> < <a href="https://www.viewsonic.com/de/">https://www.viewsonic.com/de/</a> >
<b>Қазақстан</b>	<a href="https://www.viewsonic.com/kz/">https://www.viewsonic.com/kz/</a> < <a href="https://www.viewsonic.com/kz/">https://www.viewsonic.com/kz/</a> >
<b>Россия</b>	<a href="https://www.viewsonic.com/ru/">https://www.viewsonic.com/ru/</a> < <a href="https://www.viewsonic.com/ru/">https://www.viewsonic.com/ru/</a> >
<b>España</b>	<a href="https://www.viewsonic.com/es/">https://www.viewsonic.com/es/</a> < <a href="https://www.viewsonic.com/es/">https://www.viewsonic.com/es/</a> >
<b>Türkiye</b>	<a href="https://www.viewsonic.com/tr/">https://www.viewsonic.com/tr/</a> < <a href="https://www.viewsonic.com/tr/">https://www.viewsonic.com/tr/</a> >
<b>Україна</b>	<a href="https://www.viewsonic.com/ua/">https://www.viewsonic.com/ua/</a> < <a href="https://www.viewsonic.com/ua/">https://www.viewsonic.com/ua/</a> >
<b>United Kingdom</b>	<a href="https://www.viewsonic.com/uk/">https://www.viewsonic.com/uk/</a> < <a href="https://www.viewsonic.com/uk/">https://www.viewsonic.com/uk/</a> >

## Limited Warranty

---

ViewSonic® Display

### What the warranty covers:



ViewSonic® warrants its products to be free from defects in material and workmanship during the warranty period. If a product proves to be defective in material or workmanship during the warranty period, ViewSonic® will, at its sole option, and as your sole remedy, repair or replace the product with a similar product. Replacement Product or parts may include remanufactured or refurbished parts or components. The repair or replacement unit or parts or components will be covered by the balance of the time remaining on the customer's original limited warranty and the warranty period will not be extended. ViewSonic® provides no warranty for any third-party software whether included with the product or installed by the customer, installation of any unauthorized hardware parts or components (e.g. Projector Lamps). (Please refer to: "What the warranty excludes and does not cover" section).

### **How long the warranty is effective:**

ViewSonic® displays are warranted for between 1 and 3 years, depending on your country of purchase, for all parts including the light source and for all labor from the date of the first consumer purchase.

### **Who the warranty protects:**

This warranty is valid only for the first consumer purchaser.

### **What the warranty excludes and does not cover:**

- Any product on which the serial number has been defaced, modified, or removed.
- Damage, deterioration, or malfunction resulting from:
  - Accident, misuse, neglect, fire, water, lightning, or other acts of nature, unauthorized product modification, or failure to follow instructions supplied with the product.
  - Repair or attempted repair by anyone not authorized by ViewSonic®.
  - Damage to or loss of any programs, data, or removable storage media.
  - Normal wear and tear.
  - Removal or installation of the product.
- Software or data loss occurring during repair or replacement.
- Any damage of the product due to shipment.
- Causes external to the product, such as electric power fluctuations or failure.
- Use of supplies or parts not meeting ViewSonic's specifications.
- Failure of owner to perform periodic product maintenance as stated in the User Guide.
- Any other cause which does not relate to a product defect.
- Damage caused by static (non-moving) images displayed for lengthy periods of time (also referred to as image burn-in).
- Software - Any third-party software included with the product or installed by the customer.
- Hardware/Accessories/Parts/Components – Installation of any unauthorized hardware, accessories, consumable parts or components (e.g. Projector Lamps).
- Damage to, or abuse of, the coating on the surface of the display through inappropriate cleaning as described in the product User Guide.
- Removal, installation, and set-up service charges, including wall-mounting of the product.

## How to get service:

- For information about receiving service under warranty, contact ViewSonic® Customer Support (Please refer to the “Customer Service” page). You will need to provide your product’s serial number.
- To obtain warranty service, you will be required to provide: (a) the original dated sales slip, (b) your name, (c) your address, (d) a description of the problem, and (e) the serial number of the product.
- Take or ship the product, freight prepaid, in the original container to an authorized ViewSonic® service center or ViewSonic®.
- For additional information or the name of the nearest ViewSonic® service center, contact ViewSonic®.

## Limitation of implied warranties:

There are no warranties, express or implied, which extend beyond the description contained herein including the implied warranty of merchantability and fitness for a particular purpose.

## Exclusion of damages:

ViewSonic’s liability is limited to the cost of repair or replacement of the product. ViewSonic® shall not be liable for:

- Damage to other property caused by any defects in the product, damages based upon inconvenience, loss of use of the product, loss of time, loss of profits, loss of business opportunity, loss of goodwill, interference with business relationships, or other commercial loss, even if advised of the possibility of such damages.
- Any other damages, whether incidental, consequential or otherwise.
- Any claim against the customer by any other party.
- Repair or attempted repair by anyone not authorized by ViewSonic®.

## Effect of state law:

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. Some states do not allow limitations on implied warranties and/or do not allow the exclusion of incidental or consequential damages, so the above limitations and exclusions may not apply to you.

## Sales outside the U.S.A. and Canada:

For warranty information and service on ViewSonic® products sold outside of the U.S.A. and Canada, contact ViewSonic® or your local ViewSonic® dealer. The warranty period for this product in mainland China (Hong Kong, Macao, and Taiwan Excluded) is subject to the terms and conditions of the Maintenance Guarantee Card. For users in Europe and Russia, full details of warranty provided can be found at: **ViewSonic EU (<http://www.viewsonic.com/eu/>)** under “Support/Warranty Information”.

## Mexico Limited Warranty

---

## ViewSonic® Display

### What the warranty covers:

ViewSonic® warrants its products to be free from defects in material and workmanship, under normal use, during the warranty period. If a product proves to be defective in material or workmanship during the warranty period, ViewSonic® will, at its sole option, repair or replace the product with a like product. Replacement product or parts may include remanufactured or refurbished parts or components & accessories.

### How long the warranty is effective:

ViewSonic® LCD displays are warranted for between 1 and 3 years, depending on your country of purchase, for all parts including the light source and for all labour from the date of the first consumer purchase.

### Who the warranty protects:

This warranty is valid only for the first consumer purchaser.

### What the warranty excludes and does not cover:

- Any product on which the serial number has been defaced, modified, or removed.
- Damage, deterioration, or malfunction resulting from:
  - Accident, misuse, neglect, fire, water, lightning, or other acts of nature, unauthorized product modification, or failure to follow instructions supplied with the product.
  - Causes external to the product, such as electrical power fluctuations or failure.
  - Use of supplies or parts not meeting ViewSonic®'s specifications.
  - Normal wear and tear.
  - Removal or installation of the product.

### How to get service:

- For information about receiving service under warranty, contact ViewSonic® Customer Support (Please refer to the "Customer Service" page). You will need to provide your product's serial number, so please record the product information in the space provided below on your purchase for your future use. Please retain your receipt of proof of purchase to support your warranty claim.
- To obtain warranty service, you will be required to provide: (a) the original dated sales slip, (b) your name, (c) your address, (d) a description of the problem, and (e) the serial number of the product.
- Take or ship the product, freight prepaid, in the original container to an authorized ViewSonic® service center.
- Round trip transportation costs for in-warranty products will be paid by ViewSonic®.

### Limitation of implied warranties:

There are no warranties, express or implied, which extend beyond the description contained herein including the implied warranty of merchantability and fitness for a particular purpose.

**Exclusion of damages:**

ViewSonic®'s liability is limited to the cost of repair or replacement of the product. ViewSonic® shall not be liable for:

- Damage to other property caused by any defects in the product, damages based upon inconvenience, loss of use of the product, loss of time, loss of profits, loss of business opportunity, loss of goodwill, interference with business relationships, or other commercial loss, even if advised of the possibility of such damages.
- Any other damages, whether incidental, consequential or otherwise.
- Any claim against the customer by any other party.
- Repair or attempted repair by anyone not authorized by ViewSonic®.

**Contact Information for Sales & Authorized Service (Centro Autorizado de Servicio)  
within Mexico:**

Name, address, of manufacturer and importers:

México, Av. de la Palma #8 Piso 2 Despacho 203, Corporativo Interpalmas,  
Col. San Fernando Huixquilucan, Estado de México

Tel: (55) 3605-1099 <http://www.viewsonic.com/la/soporte/index.htm> <  
<http://www.viewsonic.com/la/soporte/index.htm>>

NÚMERO GRATIS DE ASISTENCIA TÉCNICA PARA TODO MÉXICO: 001.866.823.2004

**Hermosillo:**

Distribuciones y Servicios  
Computacionales SA de CV.

Calle Juárez 284 local 2

Col. Bugambillas C.P: 83140

Tel: 01-66-22-14-9005

E-Mail:

[disc2@hmo.megared.net.mx](mailto:disc2@hmo.megared.net.mx)  
(mailto:disc2@hmo.megared.net.mx)

**Villahermosa:**

Compumantenimientos Garantizados, S.A.  
de C.V.

AV. GREGORIO MENDEZ #1504

COL, FLORIDA C.P. 86040

Tel: 01 (993) 3 52 00 47 / 3522074 / 3 52  
20 09

E-Mail:

[compumantenimientos@prodigy.net.mx](mailto:compumantenimientos@prodigy.net.mx)  
(mailto:compumantenimientos@prodigy.net.mx)

**Puebla, Pue. (Matriz):**

RENTA Y DATOS, S.A. DE C.V.

Domicilio:

29 SUR 721 COL. LA PAZ

72160 PUEBLA, PUE.

Tel: 01(52).222.891.55.77 CON  
10 LINEAS

E-Mail:

[datos@puebla.megared.net.mx](mailto:datos@puebla.megared.net.mx)  
(mailto:datos@puebla.megared.net.mx)

**Veracruz, Ver.:**

CONEXION Y DESARROLLO, S.A DE  
C.V. Av.

Americas # 419

ENTRE PINZÓN Y ALVARADO

Fracc. Reforma C.P. 91919

Tel: 01-22-91-00-31-67

E-Mail: [gacosta@qplus.com.mx](mailto:gacosta@qplus.com.mx) (mailto:  
[gacosta@qplus.com.mx](mailto:gacosta@qplus.com.mx))

**Chihuahua:**

Soluciones Globales en  
Computación

C. Magisterio # 3321 Col.  
Magisterial

Chihuahua, Chih.

Tel: 4136954

E-Mail:

[Cefeo@soluglobales.com](mailto:Cefeo@soluglobales.com) (mailto:  
[Cefeo@soluglobales.com](mailto:Cefeo@soluglobales.com))

**Cuernavaca:**

Compusupport de Cuernavaca SA de CV

Francisco Leyva # 178 Col. Miguel Hidalgo

C.P. 62040, Cuernavaca Morelos

Tel: 01 777 3180579 / 01 777 3124014

E-Mail:

[aquevedo@compusupportcva.com](mailto:aquevedo@compusupportcva.com) (mailto:  
[aquevedo@compusupportcva.com](mailto:aquevedo@compusupportcva.com))

**Distrito Federal:**

QPLUS, S.A. de C.V.

Av. Coyoacán 931

**Guadalajara, Jal.:**

SERVICRECE, S.A. de C.V.

Av. Niños Héroes # 2281

<p>Col. Del Valle 03100, México, D.F.          Tel: 01(52)55-50-00-27-35          E-Mail : <a href="mailto:gacosta@qplus.com.mx">gacosta@qplus.com.mx</a> (mailto:gacosta@qplus.com.mx)</p>	<p>Col. Arcos Sur, Sector Juárez          44170, Guadalajara, Jalisco          Tel: 01(52)33-36-15-15-43          E-Mail: <a href="mailto:mmiranda@servicrece.com">mmiranda@servicrece.com</a> (mailto:mmiranda@servicrece.com)</p>
<p><b>Guerrero Acapulco:</b>          GS Computación (Grupo Sesicomp)          Progreso #6-A, Colo Centro          39300 Acapulco, Guerrero          Tel: 744-48-32627</p>	<p><b>Monterrey:</b>          Global Product Services          Mar Caribe # 1987, Esquina con Golfo Pérsico          Fracc. Bernardo Reyes, CP 64280          Monterrey N.L. México          Tel: 8129-5103          E-Mail: <a href="mailto:aydeem@gps1.com.mx">aydeem@gps1.com.mx</a> (mailto:aydeem@gps1.com.mx)</p>
<p><b>MERIDA:</b>          ELECTROSER          Av Reforma No. 403Gx39 y 41          Mérida, Yucatán, México          CP97000          Tel: (52) 999-925-1916          E-Mail: <a href="mailto:rrrb@sureste.com">rrrb@sureste.com</a> (mailto:rrrb@sureste.com)</p>	<p><b>Oaxaca, Oax.:</b>          CENTRO DE DISTRIBUCION Y SERVICIO, S.A. de C.V.          Murguía # 708 P.A., Col. Centro, 68000, Oaxaca          Tel: 01(52)95-15-15-22-22          Fax: 01(52)95-15-13-67-00          E-Mail. <a href="mailto:gpotai2001@hotmail.com">gpotai2001@hotmail.com</a> (mailto:gpotai2001@hotmail.com)</p>
<p><b>Tijuana:</b>          STD          Av Ferrocarril Sonora #3780 L-C          Col 20 de Noviembr          Tijuana, Mexico</p>	<p><b>FOR USA SUPPORT:</b>          ViewSonic® Corporation          381 Brea Canyon Road, Walnut, CA. 91789 USA          Tel: 800-688-6688  <a href="http://www.viewsonic.com">http://www.viewsonic.com</a> &lt;  <a href="http://www.viewsonic.com">http://www.viewsonic.com</a>&gt;</p>

## Using the Monitor Safely


Please read these instructions completely before using the equipment.

- Keep this user guide in a safe place for later reference.
- Read all warnings and follow all instructions.
- Sit at least 18" (45 cm) away from the device.
- Allow at least 4" (10 cm) clearance around the device to ensure proper ventilation.
- Place the device in a well-ventilated area. Do not place anything on the device that prevents heat dissipation.
- Do not use the device near water. To reduce the risk of fire or electric shock, do not expose the device to moisture.
- Avoid exposing the device to direct sunlight or other sources of sustained heat.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other devices (including amplifiers) that may increase the temperature of the device to dangerous levels.
- Use a soft, dry cloth to clean the external housing. For more information, refer to the "Maintenance" section of this manual.
- Avoid touching the screen, as oil may collect on the screen if you touch it.
- Do not touch the screen surface with sharp or hard objects, as it may cause damage to the screen.
- Do not place the device on cloth or other materials that may be placed between the product and supporting furniture.
- When moving the device, be careful not to drop or bump the device on anything.
- Do not place the device on an uneven or unstable surface. The device may fall over resulting in an injury or a malfunction.
- Do not place any heavy objects on the device or connection cables.
- Always use cabinets, stands, or installation methods recommended by the manufacturer of the device set.
- Always use furniture that can safely support the device.
- Always ensure the device is not overhanging the edge of the supporting furniture.
- Do not place the device on tall furniture, such as cupboards or bookcases, without anchoring both the furniture and the device to a suitable support.
- Always educate children about the dangers of climbing on furniture to reach the device or related equipment.
- Do not place the monitor where children are likely to be present.
- Do not place items that might tempt children to climb, such as toys and remote controls, on the top of the device or furniture on which the product is placed.
- If smoke, an abnormal noise, or a strange odor is present, immediately turn the device off and call your dealer or ViewSonic®. It is dangerous to continue using the device.
- Do not attempt to circumvent the safety provisions of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding-type plug has two blades and a third grounding prong. The wide blade and the third prong are provided for your safety. If the plug does not fit into your outlet, obtain an adapter and do not attempt to force the plug into the outlet.
- When connecting to a power outlet, Do not remove the grounding prong. Please ensure grounding prongs are never removed.

- Always route and manage cords and cables connected to your device so they cannot be tripped over, pulled, or grabbed.
- Protect the power cord from being treaded upon or pinched, particularly at the plug, and at the point where it emerges from the equipment. Ensure that the power outlet is located near the equipment so that it is easily accessible.
- Disconnect the power plug from the power outlet if the device is not being used for a long period of time.
- Please confirm the distribution system installed in the building. The system should provide a circuit breaker rated at 120/240V, 20A.
- Only use attachments/accessories, such as carts, stands, tripods, brackets or tables, specified by the manufacturer.
- When a cart is used, use with caution when moving the cart/equipment combination to avoid injury from tipping over.
- Refer all servicing to qualified service personnel. Service will be required when the unit has been damaged in any way, such as:
  - if the power-supply cord or plug is damaged.
  - if liquid is spilled onto or objects fall into the unit.
  - if the unit is exposed to rain or moisture.
  - if the unit does not operate normally or has been dropped.
- When using ear-/headphones, adjust the volume to appropriate levels, or hearing damage may result.
- Stability Hazard: The display may fall, causing serious personal injury or death. To prevent injury, this display must be securely attached to the floor/wall in accordance with the installation instructions.
- Fastening the display to a wall or fixed object using cordage or other restraining devices can help support the weight of the display in order to prevent the display from falling over.



Hole Pattern (W x H)	Interface Pad (W x H x D)	Pad Hole	Screw Specification & Quantity
100 x 100 mm	115 x 115 x 2.6 mm	Ø 5 mm	M4 x 10 mm - 4 pieces



### NOTE:

- Restraining device/cordage should be able to withstand 100N force.
  - Make sure the cordage is straightened, and any slack is removed. The back of the device shall face the wall to ensure the device cannot tilt under external force.
  - Make sure the display does not tilt under external force at any height and rotation angle of the device.
- If the existing display is going to be retained and relocated, the same considerations as above should be applied.

## Glossary of Terms

**NOTE:** Some terms may not be applicable to your device.

### ABCFGHILMOPRSTUVY<sup>1</sup>

#### Advanced DCR

Advanced DCR technology automatically detects the image signal and intelligently controls the backlight brightness and color to improve on the ability to make the black blacker in a dark scene, and make the white whiter in a bright environment.

#### Advanced Gamma

Allows the user to manually adjust the brightness level of the monitor's grayscale levels. There are five selections: 1.8, 2.0, 2.2, 2.4, and 2.6.

#### Advanced Sharpness

Adjusts the picture quality of the monitor, with a range of 0 to 100.

## All Recall

Returns the adjustments back to factory settings if the display is operating in a factory Preset Timing Mode listed in the Specifications of this manual.

## Audio Adjust

Adjusts the volume, mutes the sound, or toggles between inputs if you have more than one source.

## Troubleshooting Common Problems

<b>Why is there no power?</b>	▼
<b>Why is there no image on screen?</b>	▼
<b>What should I do if the colors are wrong or abnormal?</b>	▼
<b>How do I adjust the screen when it is too bright or dark?</b>	▼
<b>What should I do if the screen image cuts in and out?</b>	▼
<b>The screen image is blurry, now what?</b>	▼
<b>How to center the screen properly?</b>	▼
<b>Why does the screen look yellow?</b>	▼
<b>Why can't I see the OSD Menu? And why aren't the controls accessible?</b>	▼
<b>What should I do if the Control Panel Keys aren't working?</b>	▼
<b>Why are some menus not selectable in the OSD Menu?</b>	▼
<b>Why is there no audio output?</b>	▼
<b>Why won't the connected USB devices work?</b>	▼

# Maintaining the Monitor

## General Precautions

- Make sure the monitor is turned off and the power cable is unplugged from the power outlet.
- Never spray or pour any liquid directly onto the screen or case.
- Handle the monitor with care, as a darker-colored monitor, if scuffed, may show marks more clearly than a lighter-colored monitor.

## Cleaning the Screen

- Wipe the screen with a clean, soft, lint-free cloth. This removes dust and other particles.
- If the screen is still not clean, apply a small amount of non-ammonia, non-alcohol based glass cleaner onto a clean, soft, lint-free cloth; then wipe the screen.

## Cleaning the Case

- Use a soft, dry cloth.
- If the case is still not clean, apply a small amount of non-ammonia, non-alcohol based, mild non-abrasive detergent onto a clean, soft, lint-free cloth, then wipe the surface.

## Disclaimer

- ViewSonic® does not recommend the use of any ammonia or alcohol-based cleaners on the display screen or case. Some chemical cleaners have been reported to damage the screen and/or case of the monitor.
- ViewSonic® will not be liable for damage resulting from use of any ammonia or alcohol-based cleaners.

---

Источник — [https://manuals.viewsonic.com/index.php?title=VP2776\\_Full\\_Guide&oldid=24558](https://manuals.viewsonic.com/index.php?title=VP2776_Full_Guide&oldid=24558) <  
[https://manuals.viewsonic.com/index.php?title=VP2776\\_Full\\_Guide&oldid=24558](https://manuals.viewsonic.com/index.php?title=VP2776_Full_Guide&oldid=24558)>